



BOSCH

Register your
new appliance
now at MyBosch and
enjoy benefits free of
charge:
[bosch-home.com/
welcome](https://bosch-home.com/welcome)



Washing machine

WLZ24200ME

[en] User manual and installation instructions



**You can find additional information and explanations online.
Scan the QR code on the title page.**



Table of contents

1 Safety	3	11 Laundry	23
1.1 General information	3	11.1 Preparing the laundry	23
1.2 Intended use	3	11.2 Care symbols on the care labels	23
1.3 Restriction on user group	3	12 Detergents and care products	23
1.4 Safe installation	4	13 Basic operation	24
1.5 Safe use	6	13.1 Switching on the appliance ..	24
1.6 Safe cleaning and maintenance	7	13.2 Setting a programme	24
2 Preventing material damage	8	13.3 Opening the door	24
3 Environmental protection and saving energy	9	13.4 Loading laundry	24
3.1 Disposing of packaging	9	13.5 Inserting the measuring aid ..	24
3.2 Save energy and conserve resources	9	13.6 Adding detergent and care product	25
3.3 Energy saving mode	10	13.7 Starting the programme	25
4 Installation and connection	10	13.8 Soaking laundry	25
4.1 Unpacking the appliance	10	13.9 Adding laundry	25
4.2 Contents of package	10	13.10 Cancelling the programme	25
4.3 Requirements for the installation location	10	13.11 Unloading the laundry	26
4.4 Removing foam parts	11	13.12 Switching off the appliance	26
4.5 Removing the transit bolts	11	14 Childproof lock	26
4.6 Connecting the appliance	12	14.1 Activating the childproof lock	26
4.7 Aligning the appliance	13	14.2 Deactivating the childproof lock	26
5 Before using for the first time ..	14	15 Cleaning and servicing	26
5.1 Starting an empty washing cycle	14	15.1 Cleaning the drum	26
6 Familiarising yourself with your appliance	15	15.2 Cleaning the detergent drawer	27
6.1 Appliance	15	15.3 Cleaning the drain pump	27
6.2 Detergent drawer	15	15.4 Cleaning the rubber gasket ..	29
6.3 Control panel	16	16 Troubleshooting	30
7 Display	16	17 Transportation, storage and disposal	34
8 Buttons	18	17.1 Removing the appliance	34
9 Programmes	19		
10 Accessories	22		

17.2 Inserting the transit bolts	34	18.1 Product number (E-Nr.) and production number (FD)	35
17.3 Using the appliance again	34	19 Consumption values	35
17.4 Disposing of old appliance ...	35	20 Technical data	37
18 Customer Service	35		



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 2000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- ▶ Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ▶ Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ▶ The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the  mark.
- ▶ Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
- ▶ Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

- ▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ▶ Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer . No other installation method is permitted.
- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ▶ Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

- ▶ Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

- ▶ Do not move the appliance by holding onto protruding parts.

⚠ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- ▶ Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

⚠ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ▶ Call customer service. → *Page 35*

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

When spinning larger, waterproof items of laundry, imbalances may arise and lead to injuries.

- ▶ Do not wash and spin larger items of laundry, such as blankets or mattress covers, in the appliance.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ▶ Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.

- Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with flammable cleaning agents that contain solvents may cause an explosion in the appliance.

- Rinse pretreated laundry thoroughly with water before washing.

⚠ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

- Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- Do not sit on or lean against the appliance door.

- Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

- Wait for the drum to come to a complete stop before reaching inside.

⚠ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

- Do not touch the hot detergent solution.

⚠ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance.

Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- If accidentally swallowed, seek medical advice.
- Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

⚠ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

- ▶ Only use the manufacturer's original spare parts and original accessories.

WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

- ▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

- ▶ Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- ▶ Observe the maximum load capacity for each programme and do not exceed it. → *Page 19*

The appliance is secured for transportation using transit bolts.

Transit bolts which have not been removed may result in material damage and damage to the appliance.

- ▶ Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- ▶ Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- ▶ Tighten the screw connections on the water inlet until they are hand-tight.
- ▶ Connect the water inlet hose directly to the water tap, without any additional connecting elements

such as adapters, extensions or valves.

- ▶ Ensure that the inner diameter of the water tap is at least 17 mm.
- ▶ Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ▶ Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the water connection and the hose set of the appliance.
- ▶ Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- ▶ Never kink, crush, modify or cut through water hoses.
- ▶ Only use the water hoses supplied with the appliance or genuine spare hoses.
- ▶ Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

- ▶ Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.

- ▶ Do not use hard scouring pads or cleaning sponges.
- ▶ Clean the appliance with nothing but water and a soft, damp cloth.
- ▶ Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

- ▶ Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

- Choose programs with low temperatures and longer wash times and use maximum load capacity.
→ *Page 19*
- Use the economy programme settings.
- Add detergent based on the laundry's degree of soiling.
- Reduce the washing temperature for lightly and normally soiled laundry.
- Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.
- Wash the laundry without prewash.

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode.

Energy-saving mode ends when you use the appliance again.

If you do not use the appliance for an extended period, it switches itself off.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- ▶ Remove these objects, along with all supplied accessories, from the drum before starting the appliance.

1. Remove any packaging and protective covers completely from the appliance.

→ *"Disposing of packaging", Page 9*

2. Check the appliance for visible damage.
3. Open the door. → *Page 24*
4. Remove any accessories from the drum.
5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in

material damage or damage to the appliance.

- ▶ Do not operate the appliance with incomplete or defective accessories.
- ▶ Replace the accessories in question before operating the appliance.

→ *"Accessories", Page 22*

Note: The appliance has undergone a function test at the factory. This may cause water stains in the appliance, which the first wash cycle removes.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts → *Page 11*
- Cover caps
- Water inlet hose → *Page 12*

4.3 Requirements for the installation location

WARNING

Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

- ▶ Do not operate the appliance without a cover cap.

ATTENTION

If residual water in the appliance freezes, this may cause damage to the appliance.


- ▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.


- ▶ Tilt the appliance carefully.
- ▶ Transport the appliance in an upright position.

Installation location	Requirements
-----------------------	--------------


Base	Secure the appliance with fixing brackets.
------	--




Wooden joist floor	Place the appliance on a water-resistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.
--------------------	---



Kitchen unit	Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.
--------------	--



Against a wall	Do not trap the power cord or the hoses between the wall and the appliance.
----------------	---



4.4 Removing foam parts

To prevent transport damage, the appliance is protected with foam parts at the factory. Remove the foam parts before switching on the appliance.

⚠ WARNING

Risk of injury!

When the appliance is tilted, the appliance may tip over.

- Tilt the appliance carefully.


- Do not tilt the appliance on your own.

ATTENTION


If the foam material is not removed, it can cause damage to the appliance when it is operated.

- Before starting up the appliance, remove all foam parts.

1. Tilt the appliance backwards.



2. Remove the foam parts on the underside.



Do not dispose of the foam parts. Use the foam parts when transporting the appliance in the future.

Note: To insert the foam parts for transportation into the appliance, perform these steps again in the reverse order.

4.5 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport.


→ "Inserting the transit bolts",
Page 34

Requirement: The foam parts are removed. → Page 11

1. Pull the hose out of the holders.
2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 10 wrench.



3. Remove the power cable from the holder.
4. Remove the 4 sleeves.



5. Put on the 4 cover caps.

Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.

4.6 Connecting the appliance


Connecting the water inlet hose

ATTENTION


Material damage may be caused if the water inlet hose is connected incorrectly.

- ▶ Tighten the screw connections on the water inlet until they are hand-tight.

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.


ATTENTION

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

- ▶ Secure the water outlet hose against unintentional loosening.
- In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.
- ▶ Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Note: Observe the draining heights. The draining heights are: minimum: 60 cm, maximum: 100 cm

Siphon




Secure the connection point with a (24–40 mm) hose clamp.

Sink



Fix and secure the water outlet hose with an elbow.

Plastic pipe with rubber sleeve



Fix and secure the water outlet hose with an elbow.

Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should in-


clude a residual current circuit-breaker.

1. Insert the mains plug of the appliance's power cable in a socket nearby.
The connection details of the appliance can be found under Technical data → *Page 37*.
2. Check the mains plug is inserted properly.

4.7 Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

1. Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction.




en Before using for the first time

2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.



In doing so, hold the foot tight and do not adjust its height.

5 Before using for the first time


Prepare the appliance for use.

5.1 Starting an empty washing cycle


Your appliance was inspected thoroughly before leaving the factory. To

remove any residual water, run the first wash cycle without any laundry.

1. Press and hold **Выбор темп.** 3 сек. for approx. 3 seconds.
2. Close the door.
3. Pull out the detergent drawer.
4. Pour approx. 1 litre of tap water into compartment II.



5. Add washing powder containing oxygen bleach to compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

6. Push in the detergent drawer.
7. Start the programme. → Page 25

6 Familiarising yourself with your appliance

6.1 Appliance

You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1 Maintenance flap for the drain pump → *Page 27*

2 Door → *Page 24*

3 Detergent drawer → *Page 15*

4 Control panel → *Page 16*

5 Water outlet hose → *Page 12*

6 Power cord → *Page 13*


7 Transit bolts → *Page 11*

6.2 Detergent drawer

Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and

en Display


the information in the programme descriptions.



-
- | | |
|----------|---|
| 1 | Compartment II: Detergent for the main wash |
| 2 | Compartment  : Fabric softener |
| 3 | Compartment I: Detergent for prewash |
-

6.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



1	Programmes → <i>Page 19</i>
----------	-----------------------------


2	Programme selector → <i>Page 24</i>
----------	--

3	Buttons → <i>Page 18</i> and display → <i>Page 16</i>
----------	--

7 Display

The display shows the current settings, options or relevant information.

Depending on the programme status, the display shows some information in the 8:88 area, e.g. End.



Example: Display

Display	Description
00:40 ¹	Expected programme duration or programme time remaining in hours and minutes.
🕒 / "10 h" ¹	Programme end time → <i>Page 19</i>
🌀 - 1200	Set spin speed in rpm. → <i>Page 19</i> 🌀: No spin cycle, draining only
❄️ - 90	Set temperature in °C. ❄️ (cold)
▶	Starting or pausing ■ Lights up: The programme is running and can be paused. ■ Flashes: The programme can be started or continued.
End	Programme status: Programme end
CL	■ Lights up: The childproof lock is activated. ■ Flashes: The childproof lock is activated and the appliance has been operated. → <i>Page 26</i>
🌀	The crease-reduction function is activated.
⊕	Additional rinse cycle is activated.
🌀 ⁺¹ 🌀 ⁺² 🌀 ⁺³	Additional rinse cycles are activated. → <i>Page 19</i>
🕒	Prewash is activated.
🌀	You can remove or add laundry, and interrupt the current programme. → <i>Page 25</i>
🕒	Shortened programme duration is activated.

¹ Example

Display	Description
	Energy-saving washing activated. → <i>Page 18</i>
	The "Mix" stain type is activated.
	The "Coffee" stain type is activated.
	The "Sweat" stain type is activated.
	The "Cooking fat/cooking oil" stain type is activated.
	Energy consumption  for the selected programme. ■ : Low energy consumption ■ : High energy consumption
	Water consumption for the selected programme. ■ : Low water consumption ■ : High water consumption
	The door is locked and cannot be opened. ■ To add laundry, unlock the door. → <i>Page 25</i> ■ To open the door, cancel the programme. → <i>Page 25</i>
	The drain pump is blocked. → <i>Page 30</i>
	■ No water pressure. → <i>Page 31</i> ■ The water pressure from the tap is too low.
E:35 ¹	Error code, error display, signal. → <i>Page 30</i>

8 Buttons

The selection of programme settings depends on the programme that is set.

Button	Description
 Start/Reload	Start or pause the programme.
 Eco Perfect	Activate or deactivate energy-saving washing. The temperature is reduced and the programme duration is extended. The washing result is not affected by this.
 Опции	: Activate or deactivate prewash, e.g. for washing heavily soiled laundry. Add the detergent for the prewash in compartment I and the detergent for the main wash in compartment II of the detergent drawer. → "<i>Detergent drawer</i>", <i>Page 15</i> : Activate or deactivate a shortened programme duration. The energy consumption increases. The washing result is not affected by this.

¹ Example

Button	Description
	: Activate or deactivate the reduced creasing programme. In order to reduce creasing in the laundry, the spin cycle and the spin speed are adapted. In order to reduce creasing in the laundry, the spin cycle and the spin speed are adapted. : Activate or deactivate an additional rinse cycle. All rinse cycles use hot water. Suitable for allergy sufferers and for strict hygiene requirements.
Выбор пятен	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
Отсрочка старта	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Выбор темп. 3 сек.	You can adjust the temperature by briefly pressing the button. Set temperature in °C. If you press and hold the button for around 3 seconds, you can activate the Drum Clean cycle. → <i>Page 26</i>
Скорость отжима	Adjust the spin speed or deactivate the spin cycle. If is selected, the water is drained and the spin cycle is deactivated. The laundry stays wet inside the drum.
3 сек.	Activate or deactivate the childproof lock. → <i>Page 26</i>
Доп. полоскан.	Activate or deactivate up to three additional rinse cycles. Recommended for particularly sensitive skin or in regions with very soft water.

9 Programmes

Notes

- The laundry's care labels provide you with additional information about programme selection.
→ *"Care symbols on the care labels", Page 23*
- The programme's temperature setting guarantees that the recommended temperature on the care label is not exceeded. The temperature that is reached in the appliance may differ from the set temperature. This means that the best possible washing performance is achieved with optimal energy efficiency.

Programme	Description	Max. load (kg)
Хлопок (Cottons) 	Wash hard-wearing items made from cotton or linen. Programme setting: ■ Max. 90 °C ■ Max. 1200 rpm	8.0
Эко 40-60 (Eco 40-60)	Wash items made from cotton or linen. Note: Fabrics which can be washed from 40 °C  up to 60 °C  as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature. The maximum spin speed is 1200 rpm.	8.0
Синтетика (Easy Care) 	Wash items made from synthetic fabrics. Programme setting: ■ Max. 40 °C ■ Max. 1200 rpm	4.0
Выведение пятен (Anti Stain) 	Wash items made from synthetic fabrics. Stain programme for laundry with specific stains such as blood. The washing process is adapted to the type of stain. Suitable for heavily soiled laundry. Tip: Do not let stains dry on before washing. Remove any solid residue before washing. Programme setting: ■ max. 60 °C ■ max. 1200 rpm	4.0
 Шерсть/Тонкое бельё  (Wool/Delicate)	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: ■ Max. 30 °C ■ Max. 1200 rpm	2.0

Programme	Description	Max. load (kg)
 Полоскание (Rinse)	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1200 rpm	–
  Отжим/Слив (Spin/Drain)	Spin the laundry and drain the water. Programme setting: Max. 1200 rpm	–
 Гигиена (Hygiene Plus)	Wash hard-wearing items made from cotton or linen. Suitable for allergy sufferers and for strict hygiene requirements. Note: Once the set temperature has been reached, it remains constant throughout the entire washing process. Programme setting: ■ Max. 60 °C ■ Max. 1200 rpm	4,0
 Рубашки/Блузы (Shirts)	Wash non-iron shirts and blouses made from cotton, linen or synthetic fabrics. Programme setting: ■ Max. 40 °C ■ Max. 800 rpm	4.0
Одеяла Пух. (Duvet) 	Wash pillows or quilts stuffed with synthetic fibres or down fillings. Wash large items separately. Use a detergent that is suitable for down or delicates. Use sparingly. Do not use fabric softener. Note: To prevent excessive foaming, remove air from laundry items by rolling them up before you wash them. Programme setting: ■ Max. 40 °C ■ Max. 800 rpm	3.0
Джинсы/Тёмное бельё (Dark Wash) 	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Suitable for lightly soiled laundry. Turn laundry inside-out before washing. Use liquid detergent.	4.0

Programme	Description	Max. load (kg)
	Programme setting: ■ Max. 20 °C ■ Max. 1200 rpm	
 Быстрая 59'/ 60 °C (Super Quick 59'/ 60°C)	Wash items made from cotton, linen or synthetic fabrics. Suitable for lightly and normally soiled laundry. Optimum washing results in 59 minutes. Programme setting: ■ Max. 60 °C ■ Max. 1200 rpm	8.0
 Быстрая 44'/ 40 °C (Super Quick 44'/ 40°C)	Wash items made from cotton, linen or synthetic fabrics. Suitable for lightly soiled laundry. Optimum washing results in 44 minutes. Programme setting: ■ Max. 60 °C ■ Max. 1200 rpm	8.0
 Быстрая 29'/ 30 °C (Super Quick 29'/ 30°C)	Wash items made from cotton or synthetic fabrics. Short programme for small items of lightly soiled laundry. Optimum washing results in 29 minutes. Programme setting: ■ Max. 30 °C ■ Max. 1000 rpm	4.0
 Супер Быстрая 12' (Super Quick 12')	Wash items made from cotton or synthetic fabrics. Short programme for small items of lightly soiled laundry. Programme setting: ■ Max. 30 °C ■ max. 800 rpm	2.0

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water outlet hose extension	Extend the water outlet hose (1.33 m).	17009024

11 Laundry

11.1 Preparing the laundry

ATTENTION

Objects remaining in the laundry may damage the laundry and the drum.

- ▶ Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately
- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum
- Before loading the drum, any laundry that has been pre-treated with chlorine bleach should be rinsed several times

11.2 Care symbols on the care labels

Washing care symbols

Symbol	Recommended programme
  	Cottons (normal)
	
  	Easy Care (gentle)
 	Delicates/Silk for washing by hand (particularly gentle)
	Woollens (hand wash)
	(not suitable for machine-washing)

12 Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- When using liquid detergents, only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances
- Do not use chlorine bleach
- Do not use dyes regularly as fixing salt can damage stainless steel

- Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. → *Page 10*


- ▶ Turn the programme selector to a programme.

13.2 Setting a programme


1. Turn the programme selector and set the required programme. → *Page 19*
2. If required, adjust the programme settings. → *Page 18*
The programme settings are not saved permanently for the programme.

13.3 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



13.4 Loading laundry


Note: To prevent creasing, note the maximum load for the programmes. → *Page 19*

Requirements


- The laundry is prepared and sorted. → *Page 23*
 - The drum is empty.
1. Open the door. → *Page 24*
 2. Place the laundry in the drum.
 3. Close the door.
Ensure that there is no laundry trapped in the door.

13.5 Inserting the measuring aid

1. Pull out the detergent drawer.
2. Press down on the insert ① and remove the detergent drawer ②.



3. Insert the measuring aid.



4. Push in the detergent drawer.

13.6 Adding detergent and care product

Note: Observe the information about detergents and care products
→ *Page 23*.

1. Pull out the detergent drawer.
2. If required, use the dosing aid.
3. Pour in the detergent.
→ *"Detergent drawer", Page 15*
4. If required, add the care product.
5. Push in the detergent drawer.

13.7 Starting the programme

Requirements

- A programme is set. → *Page 24*
- The door is closed.
- ▶ Press **|| ▷ Start/Reload**.
- ✓ The display shows the programme duration or the programme end time.
- ✓ After the programme has ended, the display shows: "End".

13.8 Soaking laundry

Note: No additional detergent is required for soaking. The appliance uses the filled detergent for soaking and washing.

Requirements

- The laundry is placed in the appliance. → *Page 24*

- A programme has started.
→ *Page 25*
- 1. Press **|| ▷ Start/Reload** approx. 10 minutes after the programme start.
The programme pauses and the laundry can soak.
- 2. Press **|| ▷ Start/Reload** after the required soaking time.

13.9 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

1. Press **|| ▷ Start/Reload**.
The appliance pauses.
Note: If you want to add laundry, follow the instructions on the display. → *Page 17*
2. Open the door. → *Page 24*
3. Add or remove laundry.
4. Close the door.
5. Start the programme. → *Page 25*

13.10 Cancelling the programme

1. Turn the programme selector to **Выкл..**
✓ The appliance switches off.
2. Switch on the appliance.
→ *Page 24*
3. Open the door. → *Page 24*
The appliance door remains locked for safety reasons if the temperature and water levels are high.
 - If the temperature is high, start the **Полоскание (Rinse)** programme.
 - If the water level is high, start the **Отжим** programme or select a suitable programme for draining. → *Page 19*
4. Remove the laundry. → *Page 26*

13.11 Unloading the laundry

1. Open the door. → *Page 24*
2. Remove the laundry from the drum.

13.12 Switching off the appliance

1. Turn the programme selector to **Выкл.**
2. Turn off the tap.
3. Cleaning the rubber gasket.
→ *Page 29*

Note: Leave the appliance door and the detergent drawer open to dry.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ▶ Press on both  **3 сек.** buttons for approx. 3 seconds.
- ✓ During the activation, "CL" flashes on the display.
- ✓ The display shows "CL".
- ✓ The control elements are locked.
- ✓ The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ▶ Press on both  **3 сек.** buttons for approx. three seconds.
- ✓ "CL" goes out on the display.

15 Cleaning and servicing

15.1 Cleaning the drum

Clean the drum if you have carried out 20 washing cycles at a temperature of 40 °C or lower, or if you have not used the appliance for a prolonged period, but at least once a year.

CAUTION

Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


- ▶ Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- ▶ Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ▶ Press and hold  **Выбор темп.**  **3 сек.** for approx. 3 seconds to start the drum cleaning programme. Run the programme without laundry but with washing powder that contains oxygen bleach or a cleaning agent for caring for the inside of the appliance. The programme can be started with the programme selector in any position.

15.2 Cleaning the detergent drawer


Note: Scan the QR code to see an animation of the process.




1. Pull out the detergent drawer.
2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.




4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.



7. Push in the detergent drawer.

15.3 Cleaning the drain pump


Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattling noises.

Note: Scan the QR code to see an animation of the process. Observe the following safety instructions before you start the animation.




Emptying the drain pump

1. Turn off the tap.
2. Switch off the appliance.
→ *Page 26*
3. Disconnect the appliance's mains plug from the power supply.
4. Open and remove the maintenance flap.



Use a suitable flat object, e.g. a screwdriver, to open it.


5. Slide a suitable receptacle under the opening for draining the detergent solution.



6. **⚠ CAUTION – Risk of scalding!**
When you wash at high temperatures, the detergent solution gets hot.

- ▶ Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the pump cap carefully.



Cleaning the drain pump


Requirement: The drain pump is empty. → *Page 28*

1. Clean the interior, the thread on the pump cap and the pump housing.




2. Ensure that the impeller in the drain pump can rotate.

3. Insert the pump cap.




4. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Empty the receptacle with the detergent solution.
6. Insert and close the maintenance flap.



Before the next wash


To prevent unused detergent from flowing straight into the outlet in the next wash, run a suitable programme for draining after you have emptied the drain pump.

1. Open the water tap.
2. Insert the mains plug.
3. Switch on the appliance.
4. Pour 1 litre of water into compartment II.
5. Select a suitable programme for draining. → *Page 19*

15.4 Cleaning the rubber gasket

Clean the rubber gasket regularly.

1. Open the door. → *Page 24*
2. Remove any foreign objects and fluff from the rubber gasket.



3. Clean the outside and the inside of the rubber gasket with a damp cloth and wipe dry.

16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

 WARNING
Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The detergent solution is not being pumped out. The detergent solution is not being pumped out.	The water outlet hose is connected too high, is kinked or trapped, or has been extended impermissibly. ▶ Check the installation of the water outlet hose. → <i>Page 12</i>
	Drain pipe or water outlet hose is blocked. ▶ Clean the drain pipe and the water outlet hose.
	The drain pump is blocked or the pump cover is not installed correctly. ▶ Check that the pump cover is installed correctly. → <i>Page 27</i> ▶ Clean the drain pump. → <i>Page 27</i>
	Detergent dosage is too high. ▶ Reduce the amount of detergent for the next washing cycle with the same load.
E:03 / ⓘ	Drain pump is blocked. ▶ Clean the drain pump. → <i>Page 27</i>
	The drain pump is defective. 1. Restart the appliance. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service. → <i>Page 35</i> Please specify the exact error message when calling. If possible, document the fault with photos and videos.

Fault	Cause and troubleshooting
E:02 / 	The tap is turned off. ▶ Turn on the tap. The water inlet hose is kinked or jammed. ▶ Check the installation of the water inlet hose. → <i>Page 12</i> The filters in the water inflow are blocked. ▶ Clean the filters in the water inflow. Scan the QR code to see an animation of the process. The water pressure is low. ▶ Check whether the tap has sufficient water pressure.
E:04	Critical malfunction. ▶ Turn off the water tap. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service. → <i>Page 35</i> Detergent dosage is too high. ▶ Reduce the amount of detergent for the next washing cycle with the same load. Additional water has been added. ▶ Do not add any extra water to the appliance while it is operating.
All other error codes.	Malfunction 1. Restart the appliance. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service. → <i>Page 35</i> Please specify the exact error message when calling. If possible, document the fault with photos and videos.

Fault	Cause and troubleshooting
Heavy foam build-up.	Detergent dosage is too high. ▶ Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). ▶ Reduce the amount of detergent for the next washing cycle with the same load.
E:01 / 	The door is not completely closed. 1. Ensure that there is no laundry trapped in the door. 2. Close the door.
"CL" flashes.	Childproof lock is activated. ▶ Deactivate the childproof lock. → <i>Page 26</i>
Drum rotates with blockages when moved by hand.	Not a fault. Due to its design, the drive motor cannot be turned freely by hand. No action required.
The programme does not start.	Childproof lock is activated. ▶ Deactivate the childproof lock. → <i>Page 26</i>  Отсрочка старта is activated. ▶ Check whether  Отсрочка старта is activated. → <i>Page 19</i>
The programme is paused or has been interrupted, but the door will not open.	The temperature is too high. ▶ Start the  Полоскание (Rinse) programme or wait until the temperature has dropped. Water level is too high. ▶ Start the Отжим programme or a suitable draining programme. → <i>Page 19</i>
The door cannot be opened due to a power cut.	The door is locked. ▶ Open the door using the emergency release.
Drum jerks after the programme starts.	Not a fault. An internal motor test is started. No action required.
No water is visible in the drum.	Not a fault. Water is below the visible area. No action required.
The appliance is vibrating, 'wandering' and making loud noises during the spin cycle.	Appliance is not correctly aligned. ▶ Align the appliance. → <i>Page 13</i> The appliance feet are not fixed. ▶ Secure the appliance's feet. → <i>Page 13</i> Transit bolts have not been removed. ▶ Remove the transit bolts. → <i>Page 11</i>

Fault	Cause and troubleshooting
High spin speed not reached.	The appliance is using a reduced spin speed to eliminate an imbalance. No action required.
The programme duration changes during the wash cycle.	Not a fault. The programme sequence is optimised electronically or another rinse cycle is switched on due to heavy foam build-up. No action required.
Whooshing, hissing or sucking noises.	Not a fault. Water is pumped in or detergent solution is pumped out. No action required.
Banging noises, rattling in the drain pump.	A foreign object is in the drain pump. ► Clean the drain pump. → <i>Page 27</i>
There are detergent residues on the laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. ► Start the  Полоскание (Rinse) programme or brush out the laundry after drying.
The laundry is too wet after the spinning cycle.	A low spin speed is selected. ► Start the Отжим programme. ► The next time you run a wash cycle, set a higher spin speed.
	The appliance is using a reduced spin speed to eliminate an imbalance. 1. Redistribute the laundry in the drum. 2. Start the Отжим programme.
Creasing.	The selected programme is unsuitable for the type of fabric. ► Set a suitable programme. → <i>Page 19</i>
	A high spin speed is selected. ► The next time you run a wash cycle, set a lower spin speed.
	The load is unsuitable. ► Observe the programme's maximum load capacity. → <i>Page 19</i> ► Prepare the laundry. → <i>Page 23</i>
Water is leaking out at the water inlet hose.	The water inlet hose is not correctly connected or is damaged. ► Check the installation of the water inlet hose. → <i>Page 10</i> Replace the water inlet hose if it is damaged.

Fault	Cause and troubleshooting
Water is leaking out at the water outlet hose.	The water outlet hose is not connected correctly or is damaged. ▶ Check the installation of the water outlet hose. → <i>Page 10</i> Replace the water outlet hose if it is damaged.
Water is leaking from below the door.	Dirt on the door or seal causes leaks. ▶ Clean the door and the seal.
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	There is too much detergent or fabric softener in the detergent drawer. ▶ When dosing, observe the marking in the detergent drawer. → <i>Page 25</i>
Residual water is present in the compartment  .	Insert in compartment  is blocked. ▶ Clean the detergent drawer. → <i>Page 27</i>
Fabric softener remains in the detergent drawer.	The use of fabric softener is not supported for the selected programme. ▶ Check whether the use of fabric softener is supported for the selected programme. → <i>Page 19</i>
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria. ▶ Clean the drum. → <i>Page 26</i> ▶ If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.

17 Transportation, storage and disposal

17.1 Removing the appliance

1. Turn off the tap.
2. Switch off the appliance.
→ *Page 26*
3. Unplug the appliance's mains plug.
4. Drain the water.
→ *"Cleaning the drain pump", Page 27*
5. Detach the hoses.

17.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the 4 cover caps.
Keep the cover caps.
2. Insert the 4 transit bolts.
→ *"Removing the transit bolts", Page 11*

17.3 Using the appliance again

- ▶ For further information, see Installation and connection → *Page 10* and Starting an empty washing cycle → *Page 14*.

17.4 Disposing of old appliance

Valuable raw materials can be re-used by recycling.

WARNING

Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

1. Unplug the appliance from the mains.
2. Cut through the power cord.
3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.

18 Customer Service

You can obtain function-relevant and storable genuine spare parts from our Customer Service for up to

15 years from the date on which your appliance was placed on the market. For more information, please contact our Customer Service team.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

18.1 Product number (E-Nr.) and production number (FD)

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD), which you can find on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

19 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Эко 40-60 (Eco 40-60)** are indicative only and were determined in accordance with the applicable standard EN60456.

Programme	Load (kg)	Programme duration (h:min) ¹	Energy consumption (kWh/cycle) ¹	Water consumption (l/cycle) ¹	Maximum temperature (°C) 5 mins ¹	Spin speed (rpm) ¹	Residual moisture (%) ¹
Эко 40-60 (Eco 40-60) ²	8.0	3:38	0.874	56.9	40	1200	53.40
Эко 40-60 (Eco 40-60) ²	4.0	2:48	0.305	36.5	27	1200	53.40
Эко 40-60 (Eco 40-60) ²	2.0	2:48	0.170	30.0	25	1200	53.40
Джинсы/ Тёмное бельё (Dark Wash)  20 °C	4.0	0:59	0.130	39.0	22	950	62.00
Хлопок (Cottons)  40 °C	8.0	4:30	1.110	102.0	44	950	62.00
Хлопок (Cottons)  60 °C	8.0	1:50	0.990	46.0	49	950	62.00
Выведение пятен (Anti Stain)  60 °C	4.0	2:10	1.920	95.0	57	950	62.00
Синтетика (Easy Care)  40 °C	4.0	2:30	1.130	74.0	44	950	62.00
Одеяла Пух. (Duvet)  40 °C	3.0	1:36	0.770	104.0	42	550	71.00
 Шерсть/ Тонкое бельё  (Wool/Delicate) 30 °C	2.0	0:54	0.460	62.0	27	950	62.00

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

20 Technical data

Appliance height	84.5 cm
Appliance width	59.7 cm
Appliance depth	45.8 cm
Appliance depth with door closed	51.5 cm
Appliance depth with door open	89.4 cm
Weight	62.6 kg
Maximum load	8.0 kg
Mains voltage	220-240 V, 50 Hz
⇒ Minimum installation protection	10 A
Nominal power	1850 W
Power consumption	■ Off mode: 0.50 W ■ Left-on mode: 0.50 W
Water pressure	■ Minimum: 100 kPa (1 bar) ■ Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	135 cm
Length of the water outlet hose	189 cm
Length of the power cord	160 cm



A series of horizontal lines for writing, starting with a solid line and followed by alternating solid and dashed lines.



A series of horizontal lines for writing, starting with a solid line and followed by alternating solid and dashed lines.



Many thanks for choosing a Bosch home appliance!

Register your new appliance now on MyBosch and benefit directly from:

- **Expert advice and tips to make the most of your appliance**
- **Options for warranty extension**
- **Discounts on spare parts and accessories**
- **Digital information for use and all appliance data to hand**
- **Easy access to Bosch Home Appliance Service**

Simple to register, free of charge – including on mobile devices:

www.bosch-home.com/welcome



Need some help? You can find it here.

Expert advice on your Bosch home appliances, help with problems or repairs by professionals from Bosch.

Discover all the different ways Bosch can assist you:

www.bosch-home.com/service

The contact details of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34
81739 München, GERMANY
www.bosch-home.com

A Bosch Company



9002008764 (051021)

en